

Z-MAGNETI - Zigbee Door/Window Sensor

I. Introduction

The door/window sensor detects the opening or closing of doors /Windows, combined with other equipment to achieve intelligent application scenes.

Make sure the door magnetic widget is on the side of the alignment sign

II. Specification

Name	Zigbee Door/Window Sensor
Battery Type	CR2032
Working Temperature	-10°C~55°C
Working Humidity	10%-90%RH (No Condensation)
Wireless Connection	Zigbee 3.0

III. Connect Preparation

Connect your phone to WiFi —— Smart Phone ——

WiFi Wireless Router —— Smart Host
LAN Interface LAN Interface

- Ensure that the product is within effective coverage of the smart host(Gateway) ZigBee network to ensure that the product is effectively connected to the smart host(Gateway) ZigBee network.
- Make sure the gateway is added.

IV. Download APP

Search the app store for related APP Or scan the two-dimension code on the outer packing, download and install it.

If you download APP for the first time, please click the "Registration" button to register an account;

If you already have an account, click the login button.



sensbi.com

V. Network Settings

1. Power the device on and ensure that the mobile phone has been connected to the network and has successfully added the smart gateway;
2. Open the Sensbi app, on the "smart gateway" page, click "Add Device" button and select "Door/Window Sensor" on the "Select Device Type" page.
3. Using the reset needle, press and hold reset button for more than 5s until the network indicator flashes. Add the device according to the APP instructions.
4. Once added, you can find the device in "My Home" list.

VI. Packing List

- Door/Window Sensor
- Back Gum Paste
- Battery
- Reset Needle
- Product user manual

Please read the user manual carefully before using the product.



Z-MAGNETI

Zigbee Door/Window Sensor

User Manual